

Assistive Technology Training Online

University at Buffalo - The State University of New York
USDE# H324M980014
<http://at-training.com>



Tips For Cabling the Scholar

Use a Serial-to-Parallel Converter Cable with the round end (2000 series) from Freedom Scientific to connect to Hewlett Packard Inkjet printers. Scholar will work with:

?? HP 500 series

?? HP 600 series

?? HP 800 series

Does not work with HP 700 or 900 series Inkjets!



Connect to Embosser using a serial cable (on end is round). Embosser must be set to use the serial port. Both Scholar and Embosser need to have the same serial port settings.



Purchasing the external disk drive and cable (again, with the round end for the 2000 series) makes the Scholar more versatile in the classroom as it can share information with a computer.

